

# Installation Manual

ALFA ROMEO MITO 3DR  
AR-MITO-3-A-18



## COMPONENTS INCLUDED



## FIXING CLIPS



CL-M02 x 2



# Side Shade Installation

ALFA ROMEO MITO 3DR  
AR-MITO-3-A-18

## COMPONENTS NEEDED:



CL-M02 x 2

### STEP #1

ATTACH CLIPS ON SHADE EDGES



### STEP #2

INSERT CLIPS BEHIND INTERIOR TRIM



### STEP #3

ENSURE SECURELY FITTED IN PLACE



**CAR**  
SHADES