


Flexxy measuring guide



How to measure your dog to determine dog crate size:

- L** = Nose to base of tail -> add at the least +7 cm !
- H** = Height at the withers -> add at the least +7 cm !

In case of doubt, always choose the next larger dog crate.

The mentioned dog breeds are examples only. ALWAYS measure for yourself!

	Width (cm)	Length (cm)	Height (cm)	Examples (ALWAYS measure for yourself!)
Flexxy				
XS	34,5	48,3	39,9	Cat or small dog
S	42,5	65,9	49,6	Fox Terrier, Cocker Spaniel, Beagle
M	47,8	77,8	65,8	Whippet, American Staffordshire Terrier, Chow-Chow
M wide	55,6	75,2	64,2	Whippet, American Staffordshire Terrier, Chow-Chow
L	65	90,2	72,1	Airedale Terrier, Collie, Golden Retriever
Flexxy double				
				Two dogs with separation wall 50/50
Double S	82,9	66	49,6	2x Fox Terrier, Cocker Spaniel, Beagle
Double M	93,5	78	65,8	2x Whippet, American Staffordshire Terrier, Chow-Chow

One dog, separation wall removed	
1x Whippet, American Staffordshire Terrier, Chow-Chow	
1x Boxer, German shepherd, Berger de Brie (Briard)	