

# Installation Manual

SSANGYONG RODIUS 5DR  
SSA-RODI-5-A



## COMPONENTS INCLUDED



X2



X2



X2



X2



CL-M02 x 6



CL-M12 x 2



CL-M03 x 6



CL-M04 x 4




# Installation

SSANGYONG RODIUS 5DR

SSA-RODI-5-A



## SIDE SHADE INSTALLATION





A  
X1



B  
X2



X2




# Installation

SSANGYONG RODIUS 5DR

SSA-RODI-5-A



## SIDE SHADE INSTALLATION



X2



# Installation

SSANGYONG RODIUS 5DR

SSA-RODI-5-A



## PORT/LOAD AREA SHADES INSTALLATION



X4

X2



X2

# Installation

SSANGYONG RODIUS 5DR

SSA-RODI-5-A






# Installation

SSANGYONG RODIUS 5DR

SSA-RODI-5-A

## REAR SHADE INSTALLATION



A  
X2





B  
X2



# Installation

SSANGYONG RODIUS 5DR

SSA-RODI-5-A



X2

